



Stop! Read this manual carefully before using this product!

Manual Covers The Following Products	Maximum Capacity	Maximum Suggested Weight Load
Rockit	Eight (8)	1000 lbs. (454 kg)

Contents:

Rockit – (1) Rockit tube, (1) Repair Kit

Watersports Safety Code

Watersports are fun and challenging but involve inherent risks of injury or death. To increase your enjoyment of the sport and to reduce your risks, use common sense and follow these rules:

Before you start:

- Familiarize yourself with all applicable federal, state, and local laws, the risks inherent in the sport, and the proper use of the equipment.
- Know the waterways.
- Use caution and common sense.
- Do not use in recreational swimming pools, within 3,0m (10ft.) of commercial pool edge, or within 4,5m (15ft.) of boats, docks, or other hard obstructions.
- Do not attempt or allow somersaults. Landing on the head or neck can cause serious injury, paralysis or death.
- Never use at night, or in low-light conditions.
- Never use in poor weather conditions, excessive wind, waves or lightning.
- Do not use on dry land.
- Do not use without proper anchoring.
- Do not dive head first or swim under the product.
- Take extreme care when swimming between the shore and the product. Be cautious of any boat traffic or other obstructions. Ensure all users are capable swimmers and are not excessively fatigued. Do not allow anyone to attempt to swim to or from the product that are not physically able to do so.
- Always ensure that the swimming area around the product is free of submerged logs, rocks and sandbars. Ask about the local water conditions before use.
- Only allow use of the product with proper supervision. Secure the product when not in use to prevent access by any other users.
- Do not jump or dive from this item.
- Do not jump onto this item from any other item.
- Do not use in water where there are sharks or other animals that could pose a threat to humans.
- If product is used indoors, always ensure adequate ceiling height overhead.
- Always remove personal items such as rings, watches or other sharp objects before use.

Your equipment :

- Check all equipment prior to use. Inspect your product for missing, defective or worn parts. Never use the product if excessive wear or damage are detected.
- Always check for proper inflation before each use. Temperature and environmental changes can cause changes in tube pressure. Using the product over or under inflated is dangerous and can cause damage to the product, voiding the warranty.
- Always check security of the anchor(s) and all attachments before each use.

It is the owner's responsibility to read the owner's manual and instruct all users in the safe operation of these products. By inflating these products you hereby agree to the Release of Liability, Claim Waiver, and Assumption of Risk Agreement in this manual. Please read this manual prior to inflating and using these products and keep for future reference. As with any action sport, recklessness, inexperience, misuse, or neglect of the equipment may result in serious injury or death.

⚠ WARNING

USE OF THIS PRODUCT AND PARTICIPATION IN WATERSPORTS INVOLVES INHERENT RISKS OF INJURY OR DEATH.

- This product should never be used by children except under adult supervision.
- Not intended for use by children under 5 years of age.
- This product is not a personal flotation device.
- Always wear a floatation vest (PFD) as required by the authorities in area of use.
- Never place wrists or feet through handles.
- Do not use in shallow water (less than 8 ft [2,44 m] deep).
- Do not use within 15ft (4,5 m) of shore, docks, pilings or other hard objects.
- Never swim under this product.
- Do not jump or dive from this product.
- Do not exceed the manufacturer's recommended number of users for this particular product.
- Do not use while under the influence of alcohol or drugs.
- Read Operator's Manual before use.

Made in China

⚠ CAUTION

Watersports can be safe and fun for all levels of enthusiasts. The Operator's Manual is presented to enhance your enjoyment of the sport. It is intended to alert you to some of the potentially dangerous conditions that can arise in all watersports. It is the owner's responsibility to read the owner's manual and instruct all users in the safe operation of these products. By inflating these products you hereby agree to the Release of Liability, Claim Waiver, and Assumption of Risk Agreement in the Owner's Manual.

To reduce the risk of injury or death, follow these guidelines:

- Carefully read the product Owner's Manual and follow the instructions.
- Take all reasonable precautions in the use and operation of your trampoline and/or aquapark.
- Teach anyone using your trampoline and/or aquapark about safe guidelines prior to use.
- Know your own limits. Stop when you are tired. Act responsibly. Be in good physical condition and be cautious in your use of this or any other water sports product.
- Periodically check mooring bridle and/or lines to ensure safety. Replace any portion of mooring and/or connection system that shows signs of wear.
- Do not add any hardware or attachments not otherwise supplied by the manufacturer.

THE WARNINGS AND PRACTICES SET FORTH ABOVE REPRESENT SOME COMMON RISKS ENCOUNTERED BY USERS AND DOES NOT PURPORT TO COVER ALL INSTANCES OF RISK OR DANGER. PLEASE USE COMMON SENSE AND GOOD JUDGMENT.




Please contact the dealer or manufacturer of this product if you have any questions about proper selection, function, or safe use of this product.

Made in China

- Always wear a life vest (PFD) as required by the authorities in area of use.

THE WARNINGS AND PRACTICES SET FORTH ABOVE IN THE WATERSPORTS SAFETY CODE REPRESENT SOME COMMON RISKS ENCOUNTERED BY USERS. THE CODE DOES NOT PURPORT TO COVER ALL INSTANCES OF RISK OR DANGER. PLEASE USE COMMON SENSE AND GOOD JUDGMENT.

Please contact us if you have any questions on the proper selection, function, or safe use of this product.




**NORTH SPORTS, INC.
WHITE SALMON, WA - U.S.A.
STANDARDS: EN 15649: 2012, W.A.S.
PRODUCT: ROCKIT
MADE IN P.R.C.
DESIGNED IN U.S.A.**



No protection against drowning!
Keine Schutz gegen Ertrinken!
Pas de protection contre la noyada!
No protege contra el ahogamiento!
Nessuna protezione contro l'affogamento!
Beschermt niet tegen verdrinken!



Only for swimmers!
Nur für schwimmer!
Seulement pour les nageurs!
Sólo para nadadores!
Solo per i nuotatori!
Alleen voor zwemmers!




North Sports, Inc.
#1 North Shore Dr SE
White Salmon, WA 98672
USA

Compliant with
DIN EN-15649: 2012



L: 396 cm (156")
W: 396 cm (156")
H: 168 cm (66")

WARNING



Prolonged exposure to salt water can damage and/or shorten the expected lifetime of this product. The marine environment includes many damaging elements including corrosion, abrasion and damage from marine life such as barnacles. Regular cleaning and rinsing with fresh water can reduce these risks. A PVC-safe antifouling paint should be used to help protect this product against marine growth. **DAMAGE CAUSED BY EXPOSURE TO SALT WATER IS NOT COVERED BY WARRANTY.**

Assembly

1) Locate a flat, dry area with access to electrical outlet or extension cord. **IMPORTANT:** Because of the size and weight of the Rockit, careful thought must be given to the setup area. Ideally, the Rockit tube should be carried into position while inside it's protective storage bag. The best setup position will also make launching easy. Therefore, locate the Rockit near the water's edge. **NOTE:** Dragging or sliding the Rockit over ground either before or after inflation can cause damage.

2) Once in the setup/ launch position, unfold the Rockit completely and locate the Main Valve. The Main Valve is located on the lower half of the product, near Warning Labels and in white material. See diagram for details.

3) Using a high output pump, place the inflation hose with proper adaptor into the Main Valve to inflate the Main section of the Rockit. **Inflate to 0.75 psi (0,052 bar).** Check for proper air pressure using a manometer. After inflation, replace Main Valve cover. Inflation times can vary by inflator, but the main section should be firm and tight when completely inflated. **DO NOT OVER-FILL.** Excessively high pressure can cause damage to the product and may void the warranty. Carefully monitor air pressure in the product especially during hot weather.

WARNING: Do not use an air compressor to inflate tube. Air compressors are designed for high pressure inflation and can cause tube to burst if over-inflated.

WARNING: Do not use the Rockit without adequate air pressure - **0.75 p.s.i. (0,052 bar) minimum.**

4) Next locate the Perimeter Tube Valve found above the Main Valve, and on the blue material of the perimeter tube. Follow the instructions and warnings found in Step #3 to properly inflate the perimeter section. **Inflate to 2.25 psi (0,155 bar).** Check for proper air pressure using a manometer.

5) Next inflate the 4 Saddle Chambers found just above the Perimeter Tube. Follow the instructions and warnings found in Step #3 to properly inflate the Saddle Chambers. **Inflate to 1.9 psi (0,131 bar).** Check for proper air pressure using a manometer.

6) To launch the product, make sure to have at least 4 people evenly spaced around the product to help carry it. **NEVER DRAG THE ROCKIT! YOU MUST LIFT AND SET TO AVOID ANY ACCIDENTAL TEARING AND/OR ABRASION.**

Anchoring

IMPORTANT: Proper anchoring is essential to the safety and performance of your product. Due to the wide variety of conditions, we advise using a professional skilled in mooring and anchoring, and experienced with local conditions. If improperly anchored, the product can move and/or float away. Aquaglide, Inc. is not responsible for any damage, injuries or losses due to improper anchoring.

NOTE: There are 3 heavy duty anchor rings and a short bridle underneath the Rockit. These rings are centered on the bottom side of the Rockit Main tube.

Due to the high loads that may be generated, you must use All 3 of these rings to spread the load and properly secure the product under normal conditions.

Here are some general guidelines for anchoring your product. These guidelines are not intended to replace the need for professional installation.

1) Choose a location for your Rockit. Place the product in at least 8 ft. (2,44m)

of water depth and in an area protected from the wind and boat traffic. Review your lake rules and restrictions with your local authorities.

2) Carefully check the water and seabed below the selected area for sharp or dangerous objects (i.e. rocks or stumps).

3) Keep a safe distance from docks, boats, boat lifts, and any other structures. **DO NOT** tie the product to a dock!

4) Anchors and anchor chain are sold separately. We recommend a **MINIMUM** of 200 lbs. for short-term anchoring of the Rockit in settled conditions. Heavier and/ or multiple moorings (350 - 500 lbs. or more) should be used on large, windy bodies of water.

5) Attach anchor chain securely to the anchor. Use a buoy tied to the other end of the chain to easily locate your anchor.

6) When the product is in place, remove the buoy and shackle the anchor chain to the anchor rings underneath the product. **BE SURE TO ALLOW** enough slack in the anchor chain to allow the product to move in wind or waves without displacing your mooring.

7) If strong winds or storms are expected, it is best to remove the product from the water and secure or store it.

Operation

1) This item is a circular teeter-totter for water use. Users team up on opposite sides to balance and tip the item in various directions.

2) When connecting multiple items, use only Aquaglide Interloc™ straps and connecting rings according to the Interloc™ Strap instructions provided. Make sure that the connection is tight and that there is **NO GAP** greater than 25mm (~3/4") between items. **IMPORTANT: Failure to connect these items properly may result in injury or death.**

3) We strongly recommend maintaining supervision at all times during use by a professionally certified lifeguard. **NEVER** use unattended.

4) Do not exceed the product's recommended number of users or capacity.

5) **USE COMMON SENSE.** Never jump or dive from the product. Do not allow anyone to stand on the top of the product because motion could cause a loss of balance and injury.

6) Do not swim in the area while the product is in use. Ensure that all swimmers have cleared the area before entering the water and before continuing use of the product. Never swim underneath the product.


7) The maximum weight capacity is 1000 lbs (454 Kg). It is acceptable to have up to eight people on the product. **IMPORTANT:**

- Do not exceed product weight capacity of 1000lbs. (454 kg)
- Do not concentrate more than 300 lbs. (136 kg) in any one area.
- Do not use without adequate air pressure - 0.75 p.s.i. (0,052 bar) minimum

8) If the product appears to have lost air pressure, immediately discontinue use. Check and monitor for proper air pressure and air-holding ability. Do not continue use until these are confirmed.

9) There are 2 boarding areas on the Rockit. To board, approach the boarding area and tip the Rockit toward the user with the lowest boarding handle. Climb using the handles and foot step provided. Generally it is best to allow the heaviest and/or strongest group member to board first. Once on board, group members should make sure to keep the Rockit tipped toward the boarding area, allowing remaining group members to board and assisting where necessary.

Rockit Diagram



Care and Maintenance

1) While your product has been initially treated with UV protectant, long-term exposure to sunlight will damage the product. Regularly apply a UV protectant to the exposed surface of the tube to ensure the life of your product. We recommend using ONLY 303 UV Protectant intended for use on vinyl for this purpose.

Monthly application while the product is in use is required. NOT DOING THIS WILL VOID THE WARRANTY. 303 UV Protectant is available at most watersports dealers, or online at www.303-products.com.

2) WARNING: Certain products, especially petroleum-based solvents, cleaners and protectants such as ArmorAll can damage the product and use of these products will void the warranty.

3) WARNING: Use of a high-pressure washer will damage the product and void the warranty. To clean, use a soft bristle brush with mild soap and fresh water. 303 UV Protectant contains a 'safe for vinyl' cleaner, and can be used to clean and protect the product at the same time.

4) Check the inflation of your tube often. Check for proper air pressure using a manometer. It may appear to have lost air early in the morning, but will expand once the sun warms it. Maximum expansion will occur in the heat of the day. Proper inflation is critical to the safe operation of your product and will prolong damage from wear.

Storage

1) Before storing, place the product on a clean, level area. Clean with mild soap and water and allow to dry completely. Apply 303 Protectant to all surfaces of the Rockit before deflating.

2) Remove all attachments and store in a sealed water-proof container (i.e. a plastic covered box or bin).

3) Remove ALL of the air from the tube using the deflation end of the high output inflator/deflator. If some air is left in the tube, it may freeze causing cracking.

4) Fold the deflated tube in thirds then roll loosely.

5) Store the product out of direct sunlight and protected from the environment in a clean, dry location. It is best to store inside a container with moth balls to prevent damage from rodents. NEVER store uncovered, in a damp location, or on a concrete surface! NEVER store at temperatures below 40 degrees F.

! WARNING

TO REDUCE THE RISK OF INJURY OR DEATH, FOLLOW THESE GUIDELINES:

- Do not jump or dive from the product.
- Do not stand on the top of the product.
- Do not swim, stand or climb below other climbers.
- Make sure that swimmers have cleared the entry zone before entering water.
- Do not exceed product weight capacity of 1000lbs.
- Do not concentrate more than 300 lbs. in any one area.
- Do not use without adequate air pressure

THE WARNINGS AND PRACTICES SET FORTH ABOVE REPRESENT SOME COMMON RISKS ENCOUNTERED BY USERS AND DOES NOT PURPORT TO COVER ALL INSTANCES OF RISK OR DANGER. PLEASE USE COMMON SENSE AND GOOD JUDGMENT.

WORK SPACE AND TOOLS

1. Take care to position yourself in a clean, dry area with good ventilation. For proper curing of adhesives, temperature should remain above 10°C (50 F). In most cases you will need enough room to inflate the product.
2. **Repair Kit Contents:** PVC Patch material, PVC Glue, Instructions.
3. **Additional items that MAY be needed:** Air pump, sharp scissors and/ or razor knife, dish washing liquid, water, small bowl or spray bottle, 120 Grit sandpaper, solvent such as MEK (Methyl Ethyl Ketone) or rubbing alcohol, china marker, small 'chip' brush or disposable paint brush, clean dry cloth.

LOCATE LEAK(S)

1. If there is a problem with air leaks, you will need to locate the leak(s) first.
2. Inflate your Aquaglide® Platinum™ product fully. Some small leaks can close themselves at lower air pressures, so it is best to maintain full pressure by re-inflating periodically while checking for leaks.
3. Use a soapy water solution (50%/ 50% dish soap & water) and a cloth to check for leaks. Work slowly around the product spraying or swabbing-on soapy water solution. Look for growing bubbles, which indicate a leak.
4. Once a leak is confirmed, dry the area well, mark it and prepare to patch.

PATCHING

Reinforced PVC Patch with high-grade adhesive.

**** IMPORTANT: leaks must be patched with the item completely deflated, and patches must be allowed to cure for 24 hours.**

1. DEFLATE your Aquaglide® Platinum™ product completely.
2. Carefully cut PVC patch material to size using sharp scissors or razor knife.
 - a. Patch should be least 3 - 5cm (1-2") larger than hole IN ALL DIRECTIONS around any air leak. This means a minimum patch size of 5cm x 5cm (2" x 2") for a pinhole leak. The larger the patch, the better.
 - b. Square patches with rounded corners are usually best, as this reduces the risk of peeling.
3. Dry-fit the patch over the area to be repaired to ensure good fit and coverage.
4. Use a clean 120 grit sand paper to rough up the surface to be patched AND ALSO the back of the patch material.

5. Use solvent (MEK or Rubbing Alcohol) and a fresh cloth to clean the sanded areas, removing all debris.
6. Dry-fit the patch again and use china marker (provided) to carefully outline where the patch will be located.
7. Next, use the glue (provided). Use a disposable 'chip' brush to spread glue if needed. Try to work neatly and quickly.
 - a. Using disposable brush, apply a thin, even layer of glue to the repair area making sure to cover the area completely. Stay INSIDE the china marker outline.
 - b. Using disposable brush, apply a thin, even layer of glue to the to the back of the patch making sure to cover the area completely.
 - c. Allow glue to cure for approximately 60 seconds.
 - d. Starting at one corner, carefully align the patch over the repair area using the china marker outline as a guide. Once the two surfaces touch, the bond will be immediate, so take care.
 - e. Starting at one corner and working outward, carefully apply the patch to the repair area using very firm pressure.
 - f. Rub the entire patch area and the edges of the patch using very firm pressure.
 - g. Allow to cure for at least 24 hours before inflating.



NOTICE! - Release of Liability, Claim Waiver, and Assumption of Risk Agreement

By opening and assembling this product, you are agreeing (1) to be bound to the terms set forth below and (2) to require anyone using this product to be bound by such terms. If you are unwilling to be bound by these terms, return this product (before use) for a full refund.

ASSUMPTION OF RISK: Use of this product and any of its components involves certain inherent risks, dangers, and hazards which can result in serious personal injury and death. In using the product, you freely agree to assume and accept any and all known and unknown risks of injury while using this equipment. The risks inherent in the sport can be greatly reduced by abiding by the Warning Guidelines listed in this Owner's Manual and by using common sense.

RELEASE AND WAIVER OF CLAIMS AGREEMENT: In consideration of the sale of the product to you, you hereby agree to the fullest extent permitted by law as follows:

TO WAIVE ANY AND ALL CLAIMS that you have or may in the future have against North Sports, Inc. its distributors and dealers, resulting from use of this product and any of its components.

TO RELEASE North Sports, Inc. from any and all liability for any loss, damage, injury, or expense that you or any users of this product may suffer, or that your next of kin may suffer, as a result of the use of this product, due to any cause whatsoever, including negligence or breach of contract on the part of North Sports Inc. in the design or manufacture of this product and any of its components.

ARBITRATION: In further consideration of the sale to you of this product and any of its components, you hereby agree to submit to binding arbitration any and all claims which you believe you may have against North Sports, Inc. arising from the use of any North Sports Inc. and Aquaglide® equipment or products. The arbitration shall be pursuant to the rules of the American Arbitration Association. Arbitration shall be commenced within (1) year from the date on which any alleged claim first arose. Further, the arbitration shall be held in White Salmon, Washington unless otherwise mutually agreed to by all parties. The submission to the American Arbitration Association shall be unlimited and the arbitration award may be enforced by any Court of competent jurisdiction.

BINDING EFFECT OF AGREEMENT: In the event of your death or incapacity, this Agreement shall be effective and binding upon your heirs, next of kin, executors, administrators, assigns, and representatives.

ENTIRE AGREEMENT: In entering into this Agreement, you are not relying upon any oral or written representations other than what is set forth in this agreement and the North Sports Inc. and Aquaglide® Owner's Manual.

Warranty

North Sports, Inc. warrants products to be free of defects in material or workmanship to the original purchaser for a period of Three (3) years from date of purchase. This warranty is subject to the following limitations:

1. Warranty is valid only with dated proof of purchase in the form of the original invoice.

2. Warranty is valid only when the product is used for normal recreational activities, and does not cover use in schools or rental operations. Warranty term for commercial use is 1 year.

3. Aquaglide® will make the final warranty determination which may require inspection and/or photos of the product which clearly show defect(s). We require the above be sent to another location of our choice, freight prepaid, or by email to support@aquaglide.com.

4. If a product is deemed to be defective by Aquaglide®, the warranty covers the repair or replacement of the defective product only. Aquaglide® will not be responsible for any costs, losses, or damages incurred as a result of loss of use of product.

5. This warranty does not cover damage caused by misuse, abuse, neglect, or normal wear and

tear, including, but not limited to, punctures, dragging the product over the ground, damage due to excessive sun exposure or seam failure due to overinflation in the sun, damage caused by improper handling and storage, damage caused by use in waves or shore break, and damage caused by anything other than defects in materials and workmanship.

6. This warranty is voided if any unauthorized repair, change, or modification has been made to any part of the equipment. Authorization for such must come in writing from Aquaglide®.

7. The warranty for any repaired or replacement equipment is good from the date of the original purchase only.

8. Any warranty claims must be accompanied by the original purchase receipt. The name of the retailer and date of purchase must be clear and legible.

9. There are no warranties which extend beyond the warranty specified here.

Returns and Service Policy

Product can be returned only if a return authorization number (RA) is given by Aquaglide® in advance. The RA number must be on the outside

of the package or it will not be accepted at our warehouse. Freight on the returned product must be prepaid or it will not be accepted. Upon receipt, Aquaglide® will make a determination within (30) days. If the product is covered under warranty it will be returned to the customer at the expense of North Sports, Inc. after repairs can be made. If not, the customer will receive a quote for repair and/or replacement as well as any necessary cleaning and shipping charges. The customer will have 30 days to accept the quotation. At the end of 30 days, or upon refusal of the quote, Aquaglide® will return the product in the condition in which it was received at the customer's expense. The customer agrees to authorize North Sports, Inc. to charge the customer's credit card for any costs not covered under the terms and conditions of the Aquaglide® Warranty.

Serial Number

All Aquaglide® Platinum™ products are marked with a serial number near the main inflation valve (#1). The serial number may be stamped into the PVC directly around the valve, or it may be visible on a welded plate near the valve. Please include this number when you contact Aquaglide®, or your dealer, with any warranty claim.